

Model: 9000CDT
Version: V1.55
Issue date: 28th January 2026
Type: Public

New Features

-

Improvement

- Fixed a bug when displaying CD track names

Additional information

Firmware update instructions.

1. Turn off the power supply to the device (rear panel mains switch)
2. Copy the update file onto a FAT32 formatted USB drive (folder name must be '9000CDT' and contents should be 9000CDT.bin)
3. Insert the USB drive to the 'UPDATE' USB socket on the rear panel of the device.
4. Push and hold front panel standby button.
5. Turn on the power supply to the device (rear panel mains switch) while continuing to hold the standby button.
6. Release the standby button and the display will show 'upgrade processing'.
7. Allow the device to apply the software update. This may take a few minutes.
8. When update is complete, the device is ready to use.

Change history

V1.53

Add CD Text

Add MCU ID to menu options

V1.52

Remove CD test program

V1.50

Fix a bug when displaying the total time of a CD

V1.49

Improve backlight brightness

V1.46

First release version